


HCD-S70C/S90C

SERVICE MANUAL

Ver 1.1 2001. 06

*US Model
Canadian Model
E Model
Tourist Model*



This set is the Tuner/CD player section in MHC-C7EX/MHC-C9EX.

Photo : HCD-S90C

Model Name Using Similer Mechanism	NEW
CD Mechanism Type	CDM 23X1-5BD3
Base Unit Type	BU-5BD3B
Optical Pick-up Type	KSS-240A

SPECIFICATIONS

Tuner section

FM stereo, FM/AM superheterodyne tuner

FM tuner section

Tuning range 87.5 - 108.0 MHz
Antenna terminals 75 ohm unbalanced
Intermediate frequency 10.7 MHz

AM tuner section

Tuning range
AM: 530 - 1,710 kHz
(MW) (with the AM tuning interval set at 10 kHz)
531 - 1,710 kHz
(with the AM tuning interval set at 9 kHz)
SW: 5.95 - 17.90 MHz
(E, Tourist model only)
Antenna AM loop antenna
External antenna terminals
Intermediate frequency 450 kHz

CD player section

System Compact disc digital audio system
Laser Semiconductor laser
Wavelength 780 - 790 nm
Frequency response 2 Hz - 20 kHz
Signal-to-noise ratio More than 95 dB
Dynamic range More than 90 dB

Supplied accessories

AM loop antenna (1)
Remote (1)
Sony SUM-3 (NS) batteries (2)
FM antenna (1)
Speaker cords (2) (for MHC-C7EX)
Flat cord (1)
Audio cords (2) (for MHC-C9EX) (for connecting speakers)

General

Power requirements

120 V AC, 60Hz (U.S.A. Canadian model)
120 V, 220 V,
230 V - 240 V AC
Adjustable 50/60Hz
(E, Tourist model)

Power consumption

MHC-C9EX: 80 W (U.S.A. model)
90 W (Canadian model)
100 W (E, Tourist model)
MHC-C7EX: 250 W (U.S.A. model)
350 VA (Canadian model)
180 W (E, Tourist model)

Dimensions

Approx. 280 x 205 x 315 mm
(w/h/d)
(11 1/8 x 8 1/8 x 12 1/2 inches)

Mass

Approx. 5.0 kg (11 lb 4 oz)

Design and specifications are subject to change without notice.

9-959-771-12
2001F0200-1
© 2001.6

Sony Corporation
Home Audio Company
Shinagawa Tec Service Manual Production Group

MINI Hi-Fi COMPONENT SYSTEM
SONY®

TABLE OF CONTENTS

Section	Title	Page
SECTION 1.	SERVICING NOTE	3
SECTION 2.	GENERAL	6
SECTION 3.	DISASSEMBLY	
3-1.	Case	8
3-2.	Front Panel	8
3-3.	Main Board, CD Block	9
SECTION 4.	ELECTRICAL ADJUSTMENTS	10
SECTION 5.	DIAGRAMS	
5-1.	Circuit Boards Location	14
5-2.	Semiconductor Lead Layouts	15
5-3.	Block Diagram — Tuner Section —	16
5-4.	Block Diagram — CD Section —	19
5-5.	Printed Wiring Board — Main Section —	24
5-6.	Schematic Diagram — Main Section —	27
5-7.	IC Block Diagrams — Main Section —	32
5-8.	Schematic Diagram — Panel Section —	33
5-9.	Printed Wiring Board — Panel Section —	37
5-10.	Schematic Diagram — Tuner Section —	41
5-11.	Printed Wiring Board — Tuner Section —	43
5-12.	IC Pin Functions	
	• IC201 (μ PD75516GF-572-3B9) Mechanism controller	45
	• IC601 (μ PD75518GF-243-3B9) Master control	47
	• IC701 (μ PD78043GF-097-3B9) Tuner Timer control ..	49
SECTION 6.	EXPLODED VIEWS	
6-1.	Front Panel Section	51
6-2.	CD Mechanism Section-1	52
6-3.	CD Mechanism Section-2	53
6-4.	Optical Pick-up Section	54
SECTION 7.	ELECTRICAL PARTS LIST	55

Notes on chip component replacement

- Never reuse a disconnected chip component.
- Notice that the minus side of a tantalum capacitor may be damaged by heat.

Flexible Circuit Board Repairing

- Keep the temperature of the soldering iron around 270 °C during repairing.
- Do not touch the soldering iron on the same conductor of the circuit board (within 3 times).
- Be careful not to apply force on the conductor when soldering or unsoldering.

SAFETY-RELATED COMPONENT WARNING !!

COMPONENTS IDENTIFIED BY MARK Δ OR DOTTED LINE WITH MARK Δ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

SAFETY CHECK-OUT (US model only)

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)




Fig. A. Using an AC voltmeter to check AC leakage.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE Δ SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

SECTION 1

SERVICING NOTE

NOTES ON HANDLING THE OPTICAL PICK-UP BLOCK OR BASE UNIT

The laser diode in the optical pick-up block may suffer electrostatic break-down because of the potential difference generated by the charged electrostatic load, etc. on clothing and the human body.

During repair, pay attention to electrostatic break-down and also use the procedure in the printed matter which is included in the repair parts.


The flexible board is easily damaged and should be handled with care.

NOTES ON LASER DIODE EMISSION CHECK

The laser beam on this model is concentrated so as to be focused on the disc reflective surface by the objective lens in the optical pick-up block. Therefore, when checking the laser diode emission, observe from more than 30 cm away from the objective lens.

LASER DIODE AND FOCUS SEARCH OPERATION CHECK

1. Make POWER switch on with no disc inserted and the disc table closed.
2. Confirm that the following operation is performed while observing the objective lens.



- ① Confirm that laser beam is spread.
- ② Up and down motion of the objective lens. (3 times)

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Laser component in this product is capable of emitting radiation exceeding the limit for Class 1.


CLASS 1 LASER PRODUCT
LUOKAN 1 LASERLAITE
KLASS 1 LASERAPPARAT

This appliance is classified as a CLASS 1 LASER product. The CLASS 1 LASER PRODUCT MARKING is located on the rear exterior.


CAUTION	: INVISIBLE LASER RADIATION WHEN OPEN AVOID EXPOSURE TO BEAM
ADVARSEL	: USYNLIG LASERSTRÅLING VED ÅPNING NÅR SKÅPEHEDSÅP BRYDERE ER UDE AF FUNKTION OPDAG UDSELTELSE FOR STRÅLING
VARO!	: AVATTAESSA JA SUOJALUKITUS OHITETILASSA JÄLLEÄLTÄÄ LASERSÄTEILYÄ
VARNING	: LASERSSTRÅLING NÅR DENNA DEL ÄR ÖPPNAD OCH SPÄNNEN ÄR URKOPPLAD
ADVARSEL	: USYNLIG LASERSTRÅLING NÅR DEKSEL ÅPNES UNNGÅ EKSPONERING FOR STRÅLEN

This caution label is located inside the unit.


Disc Taking Out Procedures



- 1) Insert a thin stick into the hollow of the white block and move it in the arrow direction.
(When a disc is chucked, handle the unit as follows to avoid disc removal.)




- 2) Turn the pulley A in the arrow  direction and make sure that the disc tray moves in the arrow  direction. And further turn the pulley A until the tray aligns with other trays.



- 3) Open the front panel lid. Turn the pulley B to allow the stock, which has the disc tray, to go up and down until the disc inserted tray aligns with the front panel lid position .
- 4) Turn the pulley A in the arrow ○ direction to allow the disc inserted tray to be ejected. Take out the disc and turn the pulley A in the reverse direction to allow the disc inserted tray to align with other trays.

In case two or more trays have discs, repeat step 3) and 4).



* 2 Initial setting procedures

- 1) In case turning ON the system power supply allows the mechanism to work:
First, make sure that all discs have been taken out.

Open the disc No.1.


↓
Turn OFF the system power supply.

↓
Make sure that "OFF" appears on the CD display.

↓
Blinking and character disappearing indicates setting completion.

- 2) In case turning ON the system power supply does not allow the mechanism to work:
Move the disc tray as shown in Fig.

Initial Setting Procedures



- * Make sure that all trays are in the correct positions. Turn the pulley B in the arrow direction until it stops.


SECTION 2

GENERAL

This section is extracted from instruction manual.


Front Panel

Tuner section



- 1 TIMER SET button (24)
- 2 SLEEP button (23)
- 3 CLOCK DISPLAY button (6)
- 4 CLOCK SET button (6)
- 5 TUNING indicator (12)
- 6 AUTO indicator (12)
- 7 PRESET indicator (13)
- 8 MODE button (12)
- 9 STEREO/MONO button (12)
- 10 MEMORY/NEXT button (6, 12, 13, 24)
- 11 ONCE button* (24)
- 12 DAILY button* (24)
- 13 REC TIMER button* (24)
- 14 Display window (6, 12, 13, 23, 24)
- 15 MULTI CONTROLLER (6, 12, 13, 24)
- 16 TUNER/BAND button* (12, 24)


CD player section



- 1 CHARACTER ◀/▶ buttons (8, 10)
- 2 MEMO INPUT button (10)
- 3 ERASE button (11)
- 4 S.F. FILE button (11)
- 5 CURSOR button (11)
- 6 Disc tray (7)
- 7 MEMO CHECK button (11)
- 8 DISC 1 - 5 buttons and disc tray indicator (7, 8)
- 9 OPEN/CLOSE buttons (7)
- 10 PLAY MODE buttons
 - CONTINUE (7, 9)
 - SHUFFLE (9)
 - PROGRAM (9, 17)
- 11 REPEAT button (10)
- 12 CHECK button (9)
- 13 CLEAR button (9)
- 14 EDIT button (16)
- 15 TIME button (8, 10)
- 16 CD player operating buttons
 - ▷ (play)* (7)
 - ⏏ (pause) (8)
 - (stop) (8)
 - ◀◀/▶▶▶▶ (manual search / AMS) (8)


Display Window

Tuner




- 1 Timer indication (24)
- 2 Tuner indication (12)
- 3 MEMORY indication (13)
- 4 SLEEP indication (23)
- 5 Timer program source indication (24)
- 6 Frequency/time indications (6, 12, 23, 24)
- 7 Preset radio station number (13)

CD player



- 1 Play mode indication (7, 8, 9, 10)
- 2 Playing time/disc memo indications (7, 9, 11)
- 3 S.F. FILE indication (11)
- 4 DISC MEMO indication (11)
- 5 Music calendar (7, 8)
- 6 Track indicators (7, 8)
- 7 CD editing mode indication (16)

Remote




- 1 FUNCTION button (7, 26)
- 2 TUNER BAND button (12, 24)
- 3 MD recorder operating buttons
 - ▶ (play)
 - || (pause)
 - (stop)
 - ◀ (manual search/AMS)
 - ▶ (manual search/AMS)
- 4 DISC button (8)
- 5 TUNER button (13)
- 6 CD player operating buttons
 - ▶ (play) (7)
 - || (pause) (8)
 - (stop) (8)
 - ◀ (manual search/AMS) (8)
 - ▶ (manual search/AMS) (8)
- 7 REAR LEVEL +/- buttons (for MHC-C9EX only) (22)
- 8 MODE ON button (19)
- 9 PRO LOGIC button (for MHC-C9EX only) (22)
- 10 DELAY TIME button (for MHC-C9EX only) (22)
- 11 TEST TONE button (for MHC-C9EX only) (22)
- 12 SLEEP button (23)
- 13 SYSTEM POWER switch (6)
- 14 Cassette deck operating buttons (14)
 - ▶ (front side play)
 - ◀ (reverse side play)
 - (stop)
 - ▶ (fast rightward)
 - ◀ (fast leftward)
- 15 TRACK button (8)
- 16 CD/Tuner numeric buttons (8, 13)
- 17 CENTER LEVEL +/- buttons (for MHC-C9EX only) (22)
- 18 DISC SKIP button (7)
- 19 MODE OFF button (20)
- 20 DIRECT button (MHC-C9EX) (20)
- EFFECT button (MHC-C7EX) (20)
- 21 VOL +/- button (19)
- 22 CURSOR CONTROL buttons (19)

SECTION 3


DISASSEMBLY

Note : Follow the disassembly procedure in the numerical order given.


3-1. CASE



3-2. FRONT PANEL



3-3. MAIN BOARD, CD BLOCK



SECTION 4

ELECTRICAL ADJUSTMENTS


Precautions in Repairing

If the front end unit fails, it is difficult to repair the inner circuits, so replace the entire front end unit.

FM SECTION

FM Discriminator Adjustment (NULL Adjustment)

Setting :
BAND : FM




- Procedure :**
1. Tune the set to 98MHz.
 2. Adjust IFT51 for 0Vdc reading on the VOM.

Note : FM Tuning Level adjustment should be made after FM discriminator alignment.

FM Tuned Indication Lighting Level


Setting :
BAND : FM



- Procedure :**
1. Tune the set to 98MHz.
 2. Adjust RV52 so that the TUNED indicator goes on.

FM Stereo Separation Adjustment

Setting :
BAND : FM



Procedure :
Tune the set to 98MHz.

FM stereo Signal generator output channel	VTVM connection	VTVM reading (dB)
L-CH	L-CH	Ⓐ
R-CH	L-CH	Ⓑ [Ⓐ] Adjust RV53 for minimum reading.
R-CH	R-CH	Ⓒ
L-CH	R-CH	Ⓓ [Ⓒ] Adjust RV53 for minimum reading.


L-CH Stereo separation : Ⓐ - Ⓑ[Ⓐ]
R-CH Stereo separation : Ⓒ - Ⓓ[Ⓒ]

The separations of both channels should be equal.

AM SECTION

AM Tuned Indication Lighting Level

Setting :
BAND : FM



Carrier frequency : 1050kHz
Modulation : 400Hz, 30% modulation

- Procedure :**
1. Set loop antenna A so that the loop antenna B input level becomes 55dBμ/m (0.6m V/m).
 2. Tune the set to 1050kHz
 3. Adjust RV51 so that the TUNED indicator goes on.

SW Control Voltage Adjustment
(Frequency Coverage Adjustment)
(Except US, Canadian model)

Setting :
BAND : SW


Procedure :

1. Connect digital voltmeter to diode D1 center lead and ground.
2. Adjust for a following value reading on digital voltmeter.

	Set frequency	Adjustment part	Reading on digital voltmeter
SW	f min. 5.95MHz	T2	1.2Vdc
	f max. 17.9MHz	CV2	8.5Vdc

SW Tracking Adjustment
(Except US, Canadian model)

Setting :
BAND : SW



Procedure :
 Adjust for a maximum reading on VTVM.


	Set frequency	Adjustment part
SW	7MHz	T1
	17MHz	CV1

- Repeat the procedures is each adjustment several times, and the frequency coverage and tracking adjustments should be finally done by the trimmer capacitors.

Adjustment Location:


TCB BOARD

— Component Side —




Note :

1. CD Block basically constructed to operate without adjustment. Therefore, check each item in order given.
2. Use YEDS-18 disc (3-702-101-01) unless otherwise indicated.
3. Use the oscilloscope with more than 10M Ω impedance.
4. Clean an object lens by an applicator with neutral detergent when the signal level is low than specified value with the following checks.

S Curve Check**Procedure :**


1. Connect oscilloscope to test point TP (FE) on BD board.
2. Connect between test point TP (FES) and TP (VC) by lead wire.
3. Turned Power switch on.
4. Put disc (YEDS-18) in and turned Power switch on again and actuate the focus search. (actuate the focus search when disc table is moving in and out.)
5. Check the oscilloscope waveform (S curve) is symmetrical between A and B. And confirm peak to peak level within 3 ± 1 Vp-p.

S-curve waveform



6. After check, remove the lead wire connected in step 2.

Note : • Try to measure several times to make sure that the ratio of A : B or B : A is more than 10 : 7.
• Take sweep time as long as possible and light up the brightness to obtain best waveform.

RF Level Check**Procedure :**

1. Connect oscilloscope to test point TP (RF) on BD board.
2. Turned Power switch on.



3. Put disc (YEDS-18) in and playback.

4. Confirm that oscilloscope waveform is clear and check RF signal level is correct or not.

Note :


Clear RF signal waveform means that the shape “ $\diamond$ ” can be clearly distinguished at the center of the waveform.

RF signal waveform

**E-F Balance Check****Procedure :**

1. Connect IC 201 (33) pin (MAIN BOARD) to ground and TP (TES) to TP (VC) with lead wire.
2. Connect oscilloscope to test point TP (TE) on BD board.
3. Turned Power switch on.
4. Put disc (YEDS-18) in and playback.
5. Confirm that the oscilloscope waveform is symmetrical on the top and bottom in relation to 0V, and check this level.


Traverse waveform



6. Remove the lead wire connected in step 1.

RF Free-run Frequency Check**Procedure :**


1. Connect frequency counter to IC 202 (41) pin (MAIN BOARD) with lead wire.



2. Turned Power switch on.
3. Confirm that reading on frequency counter is 4.3218MHz.


Adjustment Location :

[BD BOARD] — Conductor Side —




SECTION 5
DIAGRAMS


5-1. CIRCUIT BOARD LOCATION




5-2. SEMICONDUCTOR LEAD LAYOUTS



5-3. BLOCK DIAGRAM — TUNER SECTION —



5-4. BLOCK DIAGRAM — CD SECTION —



5-5. PRINTED WIRING BOARD — MAIN SECTION —


- See page 14 for Circuit Boards Location.
- See page 15 for Semiconductor Lead Layouts.


Semiconductor Location

Ref. No.	Location
D101	B-16
D102	B-16
D103	B-16
D104	B-16
D105	B-18
D106	B-18
D107	B-18
D108	B-18
D109	C-19
D110	D-15
D111	C-15
D112	C-15
D113	C-14
D116	C-19
D117	E-18
D118	H-19
D201	H-18
D202	H-18
D206	H-12
D207	I-13
D208	F-17
D301	E-18
D302	K-19
IC101 (BD)	B-2
IC101 (MAIN)	D-18
IC102 (BD)	B-3
IC102 (MAIN)	D-15
IC103	H-19
IC105	F-19
IC106	A-12
IC201	I-15
IC202	E-14
IC203	G-14
IC204	F-15
IC205	F-15
IC207	I-17
IC208	I-18
IC209	I-13
IC210	H-13
IC211	G-13
IC501	D-6
IC511	D-6
Q101 (BD)	B-2
Q101 (MAIN)	D-19
Q103	C-19
Q104	C-15
Q105	C-18
Q106	C-18
Q107	E-18
Q112	E-18
Q113	E-17
Q114	E-17
Q116	G-17
Q117	F-17

Note:

- : parts extracted from the component side.
- : Pattern on the side which is seen.
- : Chip components extracted from the rear side.






Note: The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.	Note: Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.
--	--


-  B+ Line
-  B- Line
-  : adjustment for repair.
- Voltage and waveforms are dc with respect to ground under no-signal (detuned) conditions.
no mark : CD PLAY
- Voltages are taken with a VOM (input impedance 10M Ω).
Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with an oscilloscope.
Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.
- Signal path.
 -  : FM
 -  : CD

5-7. IC BLOCK DIAGRAMS — MAIN SECTION —

IC101 CXA1372AQ




IC102 LA6532M




MAIN 基板


IC101 M5290P-16




IC202 CXD2500BQ




IC105 MC1452BCP




IC203 CXD2554M





IC209, 210, 211 BA6418N



5-8. SCHEMATIC DIAGRAM — PANEL SECTION —
• See page 47 for IC Pin Function. (IC601) & page 49 for IC Pin Function. (IC701)



• Waveforms




9 PANEL BOARD
IC701 9 pin
5MHz 3.86Vp-p

10 PANEL BOARD
IC601 9 pin
4.19MHz 3.86Vp-p

• IC Block Diagram

IC602 M66004FP



- Note:**
- All capacitors are in μF unless otherwise noted. pF : μF 50V or less are not indicated except for electrolytics and tantalums.
 - All resistors are in Ω and $1/4\text{W}$ or less unless otherwise specified.
 - % : indicates tolerance.
 - Δ : internal component.


Note:
The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- [B+] : B+ Line
- Voltage and waveforms are dc with respect to ground under no-signal (detuned) conditions.
- no mark : CD PLAY
- Voltages are taken with a VOM (Input impedance 10M Ω). Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with a oscilloscope. Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.
- Abbreviations
CND : Canadian model.
JE : Tourist model.
MX : Mexican model.
AR : Argentine model.

5-9. PRINTED WIRING BOARD — PANEL SECTION —

- See page 14 for Circuit Boards Location.
- See page 15 for Semiconductor Lead Layouts.






• Semiconductor Location

Ref. No.	Location
D601	E-4
D602	E-4
D603	E-4
D604	E-4
D619	H-3
D620	G-2
D621	F-2
D622	F-2
D623	F-2
D624	G-2
D625	G-2
D626	F-2
D627	F-2
D628	E-2
D629	G-2
D630	F-7
D701	D-7
D702	D-8
D703	B-8
D704	D-10
D705	D-11
D706	D-11
D707	D-3
D708	D-3
D709	D-3
D710	C-2
D711	B-5
D712	C-8
IC601	F-5
IC602	H-5
IC603	E-8
IC701	C-6
IC702	B-11
IC703	B-6
Q601	E-4
Q602	E-4
Q604	G-7
Q612	I-5
Q613	I-5
Q701	B-7
Q703	C-10
Q704	C-10
Q705	C-11
Q706	B-4
Q707	B-4
Q708	B-4
Q709	C-1
Q710	B-5

- Note:
- ○ : parts extracted from the component side.
 - ■ : Pattern on the side which is seen.
 - □ : Chip components extracted from the rear side.
 - Abbreviations
CND : Canadian model.
JE : Tourist model.
MX : Mexican model.
AR : Argentine model.

- **Waveforms**



Note:

- All capacitors are in μF unless otherwise noted. pF : μF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and 1/4W or less unless otherwise specified.
- Δ : internal component.

Note:


The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Note:


Les composants identifiés par une marque Δ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

-  : B+ Line
-  : adjustment for repair.
- Voltage and waveforms are dc with respect to ground under no-signal (detuned) conditions.
no mark : FM
() : AM (MW)
< > : SW
- Voltages are taken with a VOM (Input impedance 10MΩ).
Voltage variations may be noted due to normal production tolerances.
- Signal path.
 : FM
- Abbreviations
CND : Canadian model.
JE : Tourist model.
MX : Mexican model.
AR : Argentine model.



5-11. PRINTED WIRING BOARD — TUNER SECTION —

- See page 14 for Circuit Boards Location.
- See page 15 for Semiconductor Lead Layouts.



- Note:**
- : parts extracted from the component side.
 - : Through hole.
 - : internal component.
 - : Pattern from the side which enable seeing.
- Abbreviations
- CND : Canadian model.
 - JE : Tourist model.
 - MX : Mexican model.
 - AR : Argentine model.

Semiconductor Location	
Ref. No.	Location
D1	C-7
D21	C-4
D51	D-2
IC21	C-5
IC51	C-3
Q1	B-3
Q3	B-4
Q4	D-6
Q5	D-6
Q6	C-7
Q7	D-7
Q21	C-4
Q22	B-6
Q23	B-6
Q51	C-2
Q52	C-1
Q53	B-3

5-12. IC PIN FUNCTIONS

• IC201 (μ PD75516GF-572-3B9) Mechanism controller

Pin No.	Pin Name	I/O	Function
1			Not used (OPEN)
2	AVDD	—	+5V Power supply
3	VDD	—	
4	VDD	—	
5	E3	I	
6	E2	I	Stocker position input
7	E1	I	
8	E0	I	
9	D7	I/O	
10	D6	I/O	Data input/output pins with SRAM (IC207)
11	D5	I/O	
12	D4	I/O	
13	D3	I/O	
14	D2	I/O	
15	D1	I/O	
16	D0	I/O	
17	GFS	I	GFS signal input from DSP (IC202) “H”: OK “L”: NG
18	SENSE	I	SENSE signal input from DSP (IC202)
19	DOWN SW	I	BU down signal input
20	UP SW	I	BU up signal input
21	A11	O	Address output to SRAM (IC207)
22	A10	O	
23	A9	O	
24	A8	O	
25			Not used (OPEN)
26	LD ON	O	Laser diode ON/OFF switching output “H”: ON “L”: OFF
27	WE	O	Write enable output to SRAM (IC207)
28	A12	O	Address output to SRAM (IC207)
29	A7	O	
30	A6	O	
31	A5	O	
32	A4	O	
33	GND	—	GND
34	A3	O	Address output to SRAM (IC207)
35	A2	O	
36	A1	O	
37	A0	O	
38	QINT	O	Communication data request to Master controller (IC601)
39	M/F	I	Communication data type input from Master controller (IC601) “H”: Mechanism command “L”: File command
40	SACK	O	Communication data output to Master controller (IC601)

Pin No.	Pin Name	I/O	Function
41	MREQ	I	Communication data request from Master controller (IC601)
42	CMD3	I/O	Communication data input/output with Master controller (IC601)
43	CMD2	I/O	
44	CMD1	I/O	
45	CMD0	I/O	
46	CNIN	I	Trap jump counting input from RF servo (IC101)
47	FOK	I	Focus OK signal input from RF servo (IC101)
48	SCOR	I	Sub code sink input from DSP (IC202)
49	STOK IN	I	Tray position input
50	SUBQ	I	Sub code Q data input from DSP (IC202)
51	GND	—	GND
52	SQCK	O	Read clock output of sub code Q to DSP (IC202)
53	ADJ	I	Test mode input Normally: “H” level
54	GND	—	GND
55	XT1	I	Not used (connect to GND)
56	XT2	O	Not used (OPEN)
57	GND	—	GND
58	X1	I	Vibrator connecting pin (4.19MHz)
59	X2	O	Vibrator connecting pin (4.19MHz)
60	RESET	I	Reset signal input from Master controller (IC601)
61	D/F LATCH	O	Serial data latch output to digital filter (IC203)
62	DSP LATCH	O	Serial data latch output to DSP (IC202)
63	CLK	O	Serial data transfer clock output to DSP (IC202) and digital filter (IC203)
64	DATA	O	Serial data output to DSP (IC202) and digital filter (IC203)
65	DFCT SW	O	ON/OFF switching output of RF servo (IC101) defect circuit “L”: ON “H”: OFF
66	MUTE	O	CD output music control “H”: Mute
67	M3M	O	Clamping motor control output
68	M3P	O	
69	M2M	O	Up/down motor control output
70	M2P	O	
71	M1M	O	Loading motor control output
72	M1P	O	
73	A GND	—	GND
74	STOK OK	I	Tray position input “L”: Stocker UP/DOWN OK
75	DISC SINS	I	Disk sensor input “H”: Disk exist “L”: Disk does not exist
76	IN SW	I	Loading IN switch input
77	OUT SW	I	Loading OUT switch input
78	TEST	I	Test mode input Normally: “H” level
79	AF ADJ	I	Test mode input Normally: “H” level
80			Not used (OPEN)

• IC601 (μ PD75518GF-243-3B9) Master control

Pin No.	Pin Name	I/O	Function
1	KEY0	I	Key data input (A/D change input)
2	AV REF	—	A/D converter power supply (connect to +5V)
3	VDD	—	} +5V power supply
4	VDD	—	
5			Not used (OPEN)
6	DRIVER RESET	O	Reset signal output to CD FL tube driver (IC602)
7	ON/OFF	O	+5V power supply switch "L": OFF
8	M.C RESET	O	Reset signal output to Mechanism controller (IC201)
9			Not used (OPEN)
10	$\overline{CS}$	O	Latch signal output to CD FL tube driver (IC602)
11	AU BUS OUT	O	AU bus output
12	MREQ	O	Communication data request to Mechanism controller (IC201)
13	AU BUS/ $\overline{SIRCS}$	I	Switch AU BUS/ $\overline{SIRCS}$, fix AU BUS to "H"
14	TEST	I	Test mode pin "H": test
15	SUF.REP	I	Normally fix SUF.REP="H" and "L" becomes SHUFFLE, ALL-DISK, REP
16	D.SKIP	I	Switch Sound field/ $\overline{EDIT}$ (S632) and fix to "H" "H": Sound field file
17			} Not used (connect to +5V)
18			
19			
20			
21			
22			
23			
24	SACK	I	Serial data input from Mechanism controller (IC201)
25			} Not used (OPEN)
26			
27			
28	P60	O	Display PLAY (LED) green
29	P53	O	Disk display (LED) red (DISC4)
30	P52	O	Disk display (LED) red (DISC3)
31	P51	O	Disk display (LED) red (DISC2)
32	P50	O	Disk display (LED) red (DISC1)
33	VSS	—	GND
34	P43	O	Disk display (LED) green (DISC4)
35	P42	O	Disk display (LED) green (DISC3)
36	P41	O	Disk display (LED) green (DISC2)
37	P40	O	Disk display (LED) green (DISC1)
38	P33	O	Disk display (LED) red (DISC5)
39	P32	O	Disk display (LED) green (DISC5)
40	A SELECT	O	A-select signal output to Input selector (IC105)

Pin No.	Pin Name	I/O	Function
41	M/F	I/O	Signal type communication with Mechanism controller (IC201) "H": Mechanism command "L": File command
42			} Not used (OPEN)
43			
44			
45			
46			} Not used (connect to GND)
47			
48	QINT	I	Communication data request from Mechanism controller (IC201)
49	AU BUS IN	I	AU Bus input
50			Not used (connect to +5V)
51	DPDAT	O	Serial data output to CD FL tube driver (IC602)
52	DPCK	O	Serial data transfer clock output to CD FL tube driver (IC602)
53			Not used (connect to GND)
54	VSS	—	GND
55	XT1	—	Not used (connect to GND)
56	XT2	—	Not used (OPEN)
57	IC	—	Not used (connect to GND)
58	X1	I	System clock (4.19MHz)
59	X2	O	System clock (4.19MHz)
60	RESET	I	System reset input "L": Reset
61			} Not used (OPEN)
62			
63			
64			
65	P133	—	
66	P132	—	
67	P131	—	
68	P130	—	
69	CMD3	I/O	} Command data line with Mechanism controller (IC201)
70	CMD2	I/O	
71	CMD1	I/O	
72	CMD0	I/O	
73	AVSS	—	GND
74			} Not used (connect to GND)
75			
76			
77			
78	KEY3	I	} Key data input (A/D conversion input)
79	KEY2	I	
80	KEY1	I	

• IC701 (μ PD78043GF-097-3B9) Tuner timer control

Pin No.	Pin Name	I/O	Function
1	7G	O	Fluorescent display tube timing output
2	6G	O	
3	5G	O	
4	4G	O	
5	3G	O	
6	2G	O	
7	1G	O	
8	VDD		+5V
9	SIRCS IN	I	SIRCS signal input
10	LED REC	O	REC LED lights
11	LED DAILY	O	DAILY LED lights
12	LED ONCE	O	ONCE LED lights
13	LED PRESET	O	PRESET LED lights
14	LED AUTO-TUNING	O	AUTO-TUNING LED lights
15	LED TUNING	O	TUNING LED lights
16	LED BAND	O	BAND LED lights
17	RESET	I	Reset signal input
18	POWER	O	+12V power switch "H": OFF "L": ON
19			Not used (OPEN)
20	AVSS	—	GND
21			Not used (connect to GND)
22			
23			
24			
25			
26			Not used (connect to +5V)
27	KEY2	I	Key data input (A/D conversion input)
28	KEY1	I	
29	AVDD	—	A/D converter power supply (connect to +5V)
30	AVREF	—	A/D converter reference voltage input (connect to +5V)
31	XT1	I	Vibrator connecting pin (32kHz)
32	XT2	O	
33	VSS	—	GND
34	X1	I	Vibrator connecting pin (5MHz)
35	X2	O	
36	CE	O	Enable output to PLL (IC21)
37	D.OUT	O	Serial data output to PLL (IC21)
38	CLK	O	Serial data transfer clock output to PLL (IC21)
39	D.IN	I	Serial data input from PLL (IC21)
40	ENCODER B	I	Encoder input

Pin No.	Pin Name	I/O	Function
41	TUNED	I	TUNED signal input
42	STEREO	I	STEREO signal input
43	MUTE	O	Mute signal output
44	AUB OUT	O	AUDIO bus output
45	STOP	I	STOP signal detection pin
46	ENCODER A	I	Encoder input
47	AUB IN	I	AUDIO bus input
48		—	GND
49	FM/AM	O	Input selector (IC105) switching output "H": FM "L": AM
50	MONO	O	Forced monaural signal output "H": MONO "L": ST
51	IF OK	O	IF frequency NG output "H": NG "L": OK
52	VDD	—	+5V
53			} Not used (OPEN)
54			
55			
56			} Not used (connect to GND)
57			
58			
59			} Not used (GND)
60			
61			} Not used (OPEN)
62			
63			
64			
65			
66			
67	P10	O	} Fluorescent display tube segment output
68	P9	O	
69	P8	O	
70	P7	O	
71	VG	—	Power supply for Fluorescent display tube (–30V)
72	P6	O	} Fluorescent display tube segment output
73	P5	O	
74	P4	O	
75	P3	O	
76	P2	O	
77	P1	O	
78			Not used (OPEN)
79	9G	O	} Fluorescent display tube segment output
80	8G	O	

SECTION 6

EXPLODED VIEWS

NOTE:


- -XX, -X mean standardized parts, so they may have some difference from the original one.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list and accessories and packing materials are given in the last of this parts list.
- Abbreviation
CND : Canadian model
JE : Tourist model
AR : Argentine model
MX : Mexican model

The components identified by mark  or dotted line with mark  are critical for safety.
Replace only with part number specified.


Les composants identifiés par une marque  sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

6-1. FRONT PANEL SECTION




Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
1	4-970-382-01	KNOB (ST)		* 11	4-972-372-41	PANEL, BACK (S90C:CND)	
2	X-4945-377-1	PANEL ASSY, FRONT (S70C)		* 11	4-972-372-51	PANEL, BACK (S70C:E, MX, AR, JE)	
2	X-4945-379-1	PANEL ASSY, FRONT (S90C)		* 11	4-972-372-61	PANEL, BACK (S90C:E, MX, AR, JE)	
3	4-930-336-31	FOOT (FELT)		12	4-970-381-01	FOOT (REAR)	
4	4-812-134-00	RIVET NYLON, 3.5		13	4-951-620-01	SCREW (2.6X8), +BVTP	
* 5	A-4377-547-A	PANEL BOARD, COMPLETE(US, CND)		* 14	A-4303-461-A	TCB BOARD, COMPLETE(E, MX, AR, JE)	
* 5	A-4377-549-A	PANEL BOARD, COMPLETE(E, MX, AR, JE)		* 14	A-4303-462-A	TCB BOARD, COMPLETE(US, CND)	
6	1-769-271-11	WIRE (FLAT TYPE) (13 CORE)		15	4-972-829-01	SCREW (BIND S)	
7	1-751-690-11	WIRE (FLAT TYPE) (21 CORE)		* 16	3-309-144-21	HEAT SINK	
8	4-970-402-22	CASE		* 17	4-921-941-01	CUSHION (FL)	
9	3-704-366-01	SCREW (CASE) (M3X8)		* 18	4-960-269-01	HOLDER (FL TUBE)	
* 10	A-4377-548-A	MAIN BOARD, COMPLETE(US, CND)		* 19	4-954-701-01	HOLDER (FL TUBE)	
* 10	A-4377-550-A	MAIN BOARD, COMPLETE(E, MX, AR, JE)		* 20	4-971-717-01	HOLDER, LED	
* 11	4-970-403-32	PANEL, BACK (S70C:US)		21	4-971-718-01	COVER	
* 11	4-970-403-52	PANEL, BACK (S90C:US)		FL601	1-519-738-11	INDICATOR TUBE, FLUORESCENT	
* 11	4-972-372-31	PANEL, BACK (S70C:CND)		FLT701	1-517-215-11	INDICATOR TUBE, FLUORESCENT	

6-2. CD MECHANISM SECTION-1 (CDM23X1-5BD3)



Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
51	4-971-566-01	TABLE, DISC		66	4-954-628-01	FLANGE (PULLEY)	
52	4-971-276-01	EMBLEM (TABLE 2)		67	4-954-634-01	BELT (SL)	
53	4-971-572-01	GUIDE (ST-R)		68	4-954-629-01	PULLEY (SL)	
* 54	4-954-623-01	FULCRUM (BU)		69	3-558-708-21	WASHER, STOPPER	
55	4-971-571-01	SHAFT (TABLE GUIDE)		70	4-954-627-01	GEAR (SL)	
56	4-933-134-01	SCREW (+PTPH M2.6X6)		71	7-624-200-11	NUT, PUSH 2	
57	4-955-575-01	SPRING (BU), COMPRESSION		72	4-971-577-01	GEAR (SL2)	
58	4-929-762-01	YOKE, CHUCKING		73	3-372-516-01	PULLEY (LOADING)	
59	4-955-231-01	SPACER (MG)		74	4-954-624-01	BELT (CDM)	
60	1-452-676-11	MAGNET		* 76	4-971-565-01	HOLDER (STOCKER)	
61	4-954-650-01	HOLDER (MG)		77	4-971-568-01	SHAFT (STOCKER L)	
62	4-955-230-02	PULLEY (CHUCKING)		78	4-971-569-01	SHAFT (STOCKER S)	
* 63	X-4942-942-1	HOLDER (BU) ASSY		79	4-971-570-01	SHAFT (ST-L)	
64	4-971-574-01	SLIDER (TB)		M101	A-4660-586-A	MOTOR ASSY (LOADING MOTOR)	
* 65	4-972-058-01	FLANGE (PULLEY) (A)					


6-3. CD MECHANISM SECTION-2 (CDM23X1-5BD3)



Ref. No.	Part No.	Description
101	X-4942-939-1	SLIDER (ST-L) ASSY
102	3-558-708-21	WASHER, STOPPER
103	4-954-625-01	GEAR (CDM)
104	3-372-517-01	GEAR (LOADING)
105	4-954-624-01	BELT (CDM)
106	3-372-516-01	PULLEY (LOADING)
107	4-954-636-01	GEAR (E)
108	3-681-678-00	WASHER, SLIT
* 110	4-954-633-01	GUIDE (TB-LR)
* 111	4-954-621-01	STOPPER (TB)
112	X-4942-940-1	SLIDER (ST-R) ASSY
* 113	X-4942-937-1	CHASSIS (CDM) ASSY

Ref. No.	Part No.	Description	Remark
114	4-954-637-01	PULLEY (BU)	
115	4-954-635-01	BELT (BU)	
116	4-955-168-01	SPRING, TENSION	
* 117	4-954-632-02	LEVER (JOINT)	
118	A-4660-167-A	SLIDER (BU CAM) ASSY	
119	4-928-473-01	INSULATOR	
120	3-669-595-00	WASHER (2), STOPPER	
121	4-968-919-31	WASHER, STOPPER	
M102	A-4660-586-A	MOTOR ASSY (UP/DOWN MOTOR)	
M103	A-4660-232-A	MOTOR (CDM) ASSY (CLAMP MOTOR)	
S902	1-466-819-11	ENCODER, ROTARY	

6-4. OPTICAL PICK-UP SECTION (BU-5BD3B)



The components identified by mark $\triangle$ or dotted line with mark $\triangle$ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque $\triangle$ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description
151	4-917-565-01	SHAFT, SLED
152	4-951-940-01	INSULATOR (BU)
153	4-917-567-01	GEAR (M)
154	4-917-564-01	GEAR (P), FLATNESS
$\triangle$ 155	8-848-144-11	DEVICE, OPTICAL KSS-240A

Remark	Ref. No.	Part No.	Description	Remark
	156	1-575-001-11	WIRE, FLAT TYPE (12 CORE)	
	* 157	A-4617-371-A	BD BOARD, COMPLETE	
	158	1-751-659-11	WIRE (FLAT TYPE) (22 CORE)	
	M104	X-4917-523-4	MOTOR ASSY (SPINDLE MOTOR)	
	M105	X-4917-504-1	MOTOR ASSY (SLED MOTOR)	

BD

BD	CDM MOTOR	MAIN
----	-----------	------

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
< SWITCH >				C107	1-124-902-00	ELECT	0.47uF 20% 50V
S101	1-572-085-11	SWITCH, LEAF (LIMIT IN)		C108	1-124-443-00	ELECT	100uF 20% 10V
*****				C109	1-124-443-00	ELECT	100uF 20% 10V
* 1-654-928-11 CDM MOTOR BOARD (A~G)				C110	1-164-159-11	CERAMIC	0.1uF 50V
*****				C111	1-126-101-11	ELECT	100uF 20% 16V
< CAPACITOR >				C112	1-124-907-11	ELECT	10uF 20% 50V
C101	1-164-159-11	CERAMIC	0.1uF 50V	C113	1-164-159-11	CERAMIC	0.1uF 50V
C102	1-164-159-11	CERAMIC	0.1uF 50V	C114	1-124-477-11	ELECT	47uF 20% 25V
C103	1-164-159-11	CERAMIC	0.1uF 50V	C120	1-124-478-11	ELECT	100uF 20% 25V
< CONNECTOR >				C121	1-124-478-11	ELECT	100uF 20% 25V
* CN105	1-568-934-11	PIN, CONNECTOR 7P		C122	1-124-485-11	ELECT	330uF 20% 35V
* CN106	1-568-954-11	PIN, CONNECTOR 5P		C123	1-124-478-11	ELECT	100uF 20% 25V
< IC >				C124	1-126-101-11	ELECT	100uF 20% 16V
IC501	8-749-010-85	IC ON1024		C125	1-124-907-11	ELECT	10uF 20% 50V
IC511	8-749-010-85	IC ON1024		C126	1-124-122-11	ELECT	100uF 20% 50V
< RESISTOR >				C127	1-164-159-11	CERAMIC	0.1uF 50V
R501	1-247-811-31	CARBON	150 5% 1/4W	C128	1-164-159-11	CERAMIC	0.1uF 50V
R502	1-249-429-11	CARBON	10K 5% 1/4W	C129	1-162-306-11	CERAMIC	0.01uF 30% 16V
R511	1-247-811-31	CARBON	150 5% 1/4W	C130	1-164-159-11	CERAMIC	0.1uF 50V
R512	1-249-429-11	CARBON	10K 5% 1/4W	C131	1-124-907-11	ELECT	10uF 20% 50V
< SWITCH >				C132	1-124-903-11	ELECT	1uF 20% 50V
S101	1-571-300-21	SWITCH, ROTARY (BU UP/DOWN)		C133	1-124-903-11	ELECT	1uF 20% 50V
S103	1-692-080-11	SWITCH, PUSH (1 KEY) (TRAY IN)		C138	1-164-159-11	CERAMIC	0.1uF 50V
S103	1-692-080-11	SWITCH, PUSH (1 KEY) (TRAY OUT)		C139	1-164-159-11	CERAMIC	0.1uF 50V
*****				C141	1-162-282-31	CERAMIC	100PF 10% 50V
* A-4377-548-A MAIN BOARD, COMPLETE (US, CND)				C142	1-162-282-31	CERAMIC	100PF 10% 50V
*****				C143	1-164-159-11	CERAMIC	0.1uF 50V
* A-4377-550-A MAIN BOARD, COMPLETE (E, JE, MX, AR)				C144	1-124-927-11	ELECT	4.7uF 20% 100V
*****				C145	1-124-927-11	ELECT	4.7uF 20% 100V
* 1-690-880-31 LEAD (WITH CONNECTOR)				C146	1-164-159-11	CERAMIC	0.1uF 50V
* 3-309-144-21 HEAT SINK				C147	1-164-159-11	CERAMIC	0.1uF 50V
* 4-942-204-01 PLATE, GROUND				C148	1-101-005-00	CERAMIC	22000PF 50V
7-685-871-01 SCREW +BVT 3X6 (S)				C149	1-101-005-00	CERAMIC	22000PF 50V
< CAPACITOR >				C190	1-164-159-11	CERAMIC	0.1uF 50V
C101	1-124-119-00	ELECT	330uF 20% 16V	C191	1-161-494-00	CERAMIC	0.022uF 25V
C102	1-126-946-11	ELECT	6800uF 20% 16V	C201	1-162-282-31	CERAMIC	100PF 10% 50V
C103	1-136-165-00	FILM	0.1uF 5% 50V	C202	1-162-282-31	CERAMIC	100PF 10% 50V
C104	1-162-282-31	CERAMIC	100PF 10% 50V	C203	1-162-282-31	CERAMIC	100PF 10% 50V
C105	1-124-903-11	ELECT	1uF 20% 50V	C204	1-164-159-11	CERAMIC	0.1uF 50V
C106	1-162-302-11	CERAMIC	0.0022uF 30% 16V	C205	1-164-159-11	CERAMIC	0.1uF 50V
				C206	1-164-159-11	CERAMIC	0.1uF 50V
				C207	1-162-282-31	CERAMIC	100PF 10% 50V
				C213	1-164-159-11	CERAMIC	0.1uF 50V
				C214	1-164-159-11	CERAMIC	0.1uF 50V
				C215	1-164-159-11	CERAMIC	0.1uF 50V
				C216	1-125-486-11	DOUBLE LAYERS	0.22F 5.5V
				C217	1-164-159-11	CERAMIC	0.1uF 50V
				C218	1-162-282-31	CERAMIC	100PF 10% 50V
				C219	1-124-907-11	ELECT	10uF 20% 50V
				C220	1-136-161-00	FILM	0.047uF 5% 50V

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
C221	1-162-301-11	CERAMIC	0.0015uF 30% 16V	* CN301	1-568-832-11	SOCKET, CONNECTOR 13P	
C222	1-164-159-11	CERAMIC	0.1uF 50V	CN550	1-564-510-11	PLUG, CONNECTOR 7P	
C223	1-136-173-00	FILM	0.47uF 5% 50V	< DIODE >			
C224	1-136-153-00	FILM	0.01uF 5% 50V	D101	8-719-200-82	DIODE 11ES2	
C229	1-162-199-31	CERAMIC	10PF 5% 50V	D102	8-719-200-82	DIODE 11ES2	
C230	1-162-199-31	CERAMIC	10PF 5% 50V	D103	8-719-200-82	DIODE 11ES2	
C232	1-136-169-00	FILM	0.22uF 5% 50V	D104	8-719-200-82	DIODE 11ES2	
C233	1-164-159-11	CERAMIC	0.1uF 50V	D105	8-719-200-82	DIODE 11ES2	
C236	1-164-159-11	CERAMIC	0.1uF 50V	D106	8-719-200-82	DIODE 11ES2	
C237	1-164-159-11	CERAMIC	0.1uF 50V	D107	8-719-200-82	DIODE 11ES2	
C238	1-124-126-00	ELECT	47uF 20% 10V	D108	8-719-200-82	DIODE 11ES2	
C239	1-124-126-00	ELECT	47uF 20% 10V	D109	8-719-015-27	DIODE UZP-11BB-TP	
C240	1-124-443-00	ELECT	100uF 20% 10V	D110	8-719-200-82	DIODE 11ES2	
C241	1-124-443-00	ELECT	100uF 20% 10V	D111	8-719-016-06	DIODE UZP-30BB-TP	
C242	1-162-282-31	CERAMIC	100PF 10% 50V	D112	8-719-015-02	DIODE UZP-8.2BB	
C243	1-162-282-31	CERAMIC	100PF 10% 50V	D113	8-719-014-42	DIODE UZP-4.3BA-TP	
C248	1-124-443-00	ELECT	100uF 20% 10V	D116	8-719-987-63	DIODE 1N4148M	
C249	1-124-604-00	ELECT	330uF 20% 10V	D117	8-719-010-40	DIODE UZ-5.6BS-TP	
C250	1-164-159-11	CERAMIC	0.1uF 50V	D118	8-719-987-63	DIODE 1N4148M	
C251	1-164-159-11	CERAMIC	0.1uF 50V	D201	8-719-200-82	DIODE 11ES2	
C253	1-126-176-11	ELECT	220uF 20% 10V	D202	8-719-987-63	DIODE 1N4148M	
C254	1-124-907-11	ELECT	10uF 20% 50V	D206	8-719-200-82	DIODE 11ES2	
C255	1-126-101-11	ELECT	100uF 20% 16V	D207	8-719-200-82	DIODE 11ES2	
C256	1-124-927-11	ELECT	4.7uF 20% 100V	D208	8-719-987-63	DIODE 1N4148M	
C257	1-124-927-11	ELECT	4.7uF 20% 100V	D301	8-719-987-63	DIODE 1N4148M	
C258	1-124-907-11	ELECT	10uF 20% 50V	D302	8-719-987-63	DIODE 1N4148M	
C259	1-124-907-11	ELECT	10uF 20% 50V	< IC >			
C260	1-124-907-11	ELECT	10uF 20% 50V	IC101	8-759-630-21	IC M5290P-16	
C261	1-124-907-11	ELECT	10uF 20% 50V	IC102	8-759-604-86	IC M5F7807	
C262	1-124-907-11	ELECT	10uF 20% 50V	IC103	8-759-231-53	IC TA7805S	
C263	1-124-907-11	ELECT	10uF 20% 50V	IC105	8-759-000-48	IC MC14052BCP	
C269	1-164-159-11	CERAMIC	0.1uF 50V	IC106	8-749-921-12	IC GP1F32T (CD (OPTICAL DIGITAL OUT))	
C270	1-124-126-00	ELECT	47uF 20% 10V	IC201	8-759-295-58	IC uPD75516GF-572-3B9	
C271	1-124-604-00	ELECT	330uF 20% 10V	IC202	8-752-351-78	IC CXD2500BQ	
C272	1-164-159-11	CERAMIC	0.1uF 50V	IC203	8-752-337-10	IC CXD2554M	
< CERANUC FILTER >				IC204	8-759-155-52	IC PCM-67U-B	
CF201	1-567-775-11	VIBRATOR, CERAMIC (4.19MHz)		IC205	8-759-634-50	IC M5218AL	
< CONNECTOR >				IC207	8-759-289-95	IC LH5160TG	
CN201	1-750-923-31	HOUSING, CONNECTOR (PC BOARD) 15P (SYSTEM CONTROL)		IC208	8-759-000-58	IC MC14093BCP	
* CN202	1-565-561-11	PIN, CONNECTOR 3P (AU BUS)		IC209	8-759-501-73	IC BA6418N	
* CN205	1-568-934-11	PIN, CONNECTOR 7P		IC210	8-759-501-73	IC BA6418N	
CN206	1-506-469-11	PIN, CONNECTOR 4P		IC211	8-759-501-73	IC BA6418N	
* CN208	1-568-951-11	PIN, CONNECTOR 2P		< COIL >			
CN209	1-506-469-11	PIN, CONNECTOR 4P		L201	1-410-509-11	INDUCTOR 10uH	
* CN210	1-573-264-11	PIN, CONNECTOR 5P		L202	1-410-509-11	INDUCTOR 10uH	
* CN211	1-764-108-11	CONNECTOR, FFC 22P		L203	1-410-509-11	INDUCTOR 10uH	
CN212	1-568-838-11	SOCKET, CONNECTOR 21P		L204	1-410-513-11	INDUCTOR 22uH	

Ref. No.	Part No.	Description	Remark			Ref. No.	Part No.	Description	Remark		
< TRANSISTOR >						R212	1-249-429-11	CARBON	10K	5%	1/4W
Q101	8-729-209-15	TRANSISTOR	2SD2012			R213	1-249-429-11	CARBON	10K	5%	1/4W
Q103	8-729-900-80	TRANSISTOR	DTC114ES			R214	1-249-429-11	CARBON	10K	5%	1/4W
Q104	8-729-173-38	TRANSISTOR	2SA733-K			R215	1-249-429-11	CARBON	10K	5%	1/4W
Q105	8-729-119-78	TRANSISTOR	2SC2785-HFE			R216	1-249-429-11	CARBON	10K	5%	1/4W
Q106	8-729-141-83	TRANSISTOR	2SB1094-LK			R217	1-249-429-11	CARBON	10K	5%	1/4W
Q107	8-729-900-80	TRANSISTOR	DTC114ES			R218	1-249-429-11	CARBON	10K	5%	1/4W
Q112	8-729-900-80	TRANSISTOR	DTC114ES			R219	1-249-429-11	CARBON	10K	5%	1/4W
Q113	8-729-900-80	TRANSISTOR	DTC114ES			R220	1-249-429-11	CARBON	10K	5%	1/4W
Q114	8-729-900-61	TRANSISTOR	DTA114ES			R221	1-249-417-11	CARBON	1K	5%	1/4W
Q116	8-729-119-78	TRANSISTOR	2SC2785-HFE			R222	1-249-429-11	CARBON	10K	5%	1/4W
Q117	8-729-119-78	TRANSISTOR	2SC2785-HFE			R223	1-249-429-11	CARBON	10K	5%	1/4W
< RESISTOR >						R224	1-249-429-11	CARBON	10K	5%	1/4W
R101	1-249-425-11	CARBON	4.7K	5%	1/4W	R225	1-249-429-11	CARBON	10K	5%	1/4W
R102	1-249-425-11	CARBON	4.7K	5%	1/4W	R226	1-249-429-11	CARBON	10K	5%	1/4W
R103	1-249-421-11	CARBON	2.2K	5%	1/4W	R227	1-249-425-11	CARBON	4.7K	5%	1/4W
R104	1-249-429-11	CARBON	10K	5%	1/4W	R228	1-249-429-11	CARBON	10K	5%	1/4W
R105	1-249-429-11	CARBON	10K	5%	1/4W	R229	1-249-429-11	CARBON	10K	5%	1/4W
△R111	1-217-637-00	FUSIBLE	1	5%	1/4W F	R230	1-249-429-11	CARBON	10K	5%	1/4W
R112	1-249-413-11	CARBON	470	5%	1/4W	R231	1-249-429-11	CARBON	10K	5%	1/4W
R113	1-249-413-11	CARBON	470	5%	1/4W	R232	1-249-429-11	CARBON	10K	5%	1/4W
R114	1-249-414-11	CARBON	560	5%	1/4W	R233	1-249-429-11	CARBON	10K	5%	1/4W
R115	1-249-411-11	CARBON	330	5%	1/4W	R234	1-249-429-11	CARBON	10K	5%	1/4W
R116	1-249-411-11	CARBON	330	5%	1/4W	R235	1-249-429-11	CARBON	10K	5%	1/4W
R117	1-249-412-11	CARBON	390	5%	1/4W	R236	1-249-429-11	CARBON	10K	5%	1/4W
R118	1-249-412-11	CARBON	390	5%	1/4W	R237	1-249-429-11	CARBON	10K	5%	1/4W
R120	1-247-757-11	CARBON	2.7K	5%	1/2W	R238	1-249-417-11	CARBON	1K	5%	1/4W
R122	1-249-413-11	CARBON	470	5%	1/4W	R239	1-249-423-11	CARBON	3.3K	5%	1/4W
R132	1-249-429-11	CARBON	10K	5%	1/4W	R240	1-249-423-11	CARBON	3.3K	5%	1/4W
R133	1-247-807-31	CARBON	100	5%	1/4W	R241	1-249-429-11	CARBON	10K	5%	1/4W
R134	1-247-807-31	CARBON	100	5%	1/4W	R242	1-249-429-11	CARBON	10K	5%	1/4W
R135	1-249-437-11	CARBON	47K	5%	1/4W	R243	1-249-441-11	CARBON	100K	5%	1/4W
R136	1-249-437-11	CARBON	47K	5%	1/4W	R244	1-249-413-11	CARBON	470	5%	1/4W
R140	1-249-417-11	CARBON	1K	5%	1/4W	R245	1-249-413-11	CARBON	470	5%	1/4W
R142	1-247-757-11	CARBON	2.7K	5%	1/2W	R246	1-249-413-11	CARBON	470	5%	1/4W
△R143	1-217-640-11	FUSIBLE	3.3	5%	1/4W F	R248	1-249-409-11	CARBON	220	5%	1/4W
R144	1-249-425-11	CARBON	4.7K	5%	1/4W	R249	1-249-413-11	CARBON	470	5%	1/4W
R145	1-249-425-11	CARBON	4.7K	5%	1/4W	R250	1-249-413-11	CARBON	470	5%	1/4W
R202	1-249-423-11	CARBON	3.3K	5%	1/4W	R251	1-249-413-11	CARBON	470	5%	1/4W
R203	1-249-423-11	CARBON	3.3K	5%	1/4W	R252	1-249-413-11	CARBON	470	5%	1/4W
R204	1-249-423-11	CARBON	3.3K	5%	1/4W	R253	1-249-413-11	CARBON	470	5%	1/4W
R205	1-249-423-11	CARBON	3.3K	5%	1/4W	R254	1-249-413-11	CARBON	470	5%	1/4W
R206	1-249-429-11	CARBON	10K	5%	1/4W	R255	1-249-413-11	CARBON	470	5%	1/4W
R207	1-249-429-11	CARBON	10K	5%	1/4W	R256	1-249-421-11	CARBON	2.2K	5%	1/4W
R208	1-249-429-11	CARBON	10K	5%	1/4W	R257	1-249-421-11	CARBON	2.2K	5%	1/4W
R209	1-249-429-11	CARBON	10K	5%	1/4W	R264	1-249-408-11	CARBON	180	5%	1/4W
R210	1-249-429-11	CARBON	10K	5%	1/4W	R265	1-249-408-11	CARBON	180	5%	1/4W
R211	1-249-429-11	CARBON	10K	5%	1/4W	R266	1-249-397-11	CARBON	22	5%	1/4W
						R267	1-249-397-11	CARBON	22	5%	1/4W
						R268	1-249-417-11	CARBON	1K	5%	1/4W

The components identified by mark △ or dotted line with mark △ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark			Ref. No.	Part No.	Description	Remark		
R269	1-249-417-11	CARBON	1K	5%	1/4W	C628	1-126-948-11	ELECT	100uF	20%	35V
R270	1-249-417-11	CARBON	1K	5%	1/4W	C630	1-164-159-11	CERAMIC	0.1uF		50V
R271	1-249-417-11	CARBON	1K	5%	1/4W	C631	1-126-157-11	ELECT	10uF	20%	16V
R272	1-249-417-11	CARBON	1K	5%	1/4W	C632	1-164-159-11	CERAMIC	0.1uF		50V
R273	1-247-807-31	CARBON	100	5%	1/4W	C633	1-162-306-11	CERAMIC	0.01uF	30%	16V
R276	1-247-807-31	CARBON	100	5%	1/4W	C634	1-136-165-00	FILM	0.1uF	5%	50V
R277	1-247-807-31	CARBON	100	5%	1/4W	C635	1-136-165-00	FILM	0.1uF	5%	50V
R278	1-247-887-00	CARBON	220K	5%	1/4W	C636	1-162-282-31	CERAMIC	100PF	10%	50V
R279	1-247-887-00	CARBON	220K	5%	1/4W	C637	1-164-159-11	CERAMIC	0.1uF		50V
R280	1-249-441-11	CARBON	100K	5%	1/4W	C701	1-125-486-11	DOUBLE LAYERS	0.22F		5.5V
R281	1-249-435-11	CARBON	33K	5%	1/4W	C702	1-164-159-11	CERAMIC	0.1uF		50V
R302	1-249-429-11	CARBON	10K	5%	1/4W	C703	1-162-306-11	CERAMIC	0.01uF	30%	16V
R303	1-249-423-11	CARBON	3.3K	5%	1/4W	C704	1-162-306-11	CERAMIC	0.01uF	30%	16V
R304	1-249-429-11	CARBON	10K	5%	1/4W	C707	1-162-205-31	CERAMIC	18PF	5%	50V
R1001	1-247-807-31	CARBON	100	5%	1/4W	C708	1-162-206-31	CERAMIC	20PF	5%	50V
R1002	1-247-807-31	CARBON	100	5%	1/4W	C709	1-162-306-11	CERAMIC	0.01uF	30%	16V
R1003	1-247-807-31	CARBON	100	5%	1/4W	C710	1-136-173-00	FILM	0.47uF	5%	50V
< TRANSFORMER >						C711	1-136-173-00	FILM	0.47uF	5%	50V
△T101	1-423-771-11	TRANSFORMER, POWER									
< TERMINAL >						C713	1-126-160-11	ELECT	1uF	20%	50V
TM301	1-537-238-21	TERMINAL BOARD (ANTENNA)									
< VIBRATOR >						C714	1-126-923-11	ELECT	220uF	20%	10V
X201	1-579-280-11	VIBRATOR, CRYSTAL (16.9344MHz)									

*	A-4377-547-A	PANEL BOARD, COMPLETE (US, CND)	*****								
*	A-4377-549-A	PANEL BOARD, COMPLETE (E, JE, MX, AR)	*****								
*	4-921-941-01	CUSHION (FL)									
*	4-954-701-01	HOLDER (FL TUBE)									
*	4-960-269-01	HOLDER (FL TUBE)									
*	4-971-717-01	HOLDER, LED									
	4-971-718-01	COVER									
< CAPACITOR >						C730	1-162-286-31	CERAMIC	220PF	10%	50V
C603	1-162-302-11	CERAMIC	0.0022uF	30%	16V	C731	1-162-286-31	CERAMIC	220PF	10%	50V
C604	1-164-159-11	CERAMIC	0.1uF		50V	C732	1-162-286-31	CERAMIC	220PF	10%	50V
C606	1-164-159-11	CERAMIC	0.1uF		50V	C733	1-162-286-31	CERAMIC	220PF	10%	50V
C619	1-162-286-31	CERAMIC	220PF	10%	50V	C734	1-162-286-31	CERAMIC	220PF	10%	50V
C621	1-162-282-31	CERAMIC	100PF	10%	50V	C735	1-162-286-31	CERAMIC	220PF	10%	50V
C622	1-164-159-11	CERAMIC	0.1uF		50V	C736	1-162-286-31	CERAMIC	220PF	10%	50V
C624	1-124-584-00	ELECT	100uF	20%	10V	C737	1-162-286-31	CERAMIC	220PF	10%	50V
C625	1-124-584-00	ELECT	100uF	20%	10V	C738	1-162-286-31	CERAMIC	220PF	10%	50V
C626	1-162-286-31	CERAMIC	220PF	10%	50V	C739	1-162-286-31	CERAMIC	220PF	10%	50V
C627	1-162-286-31	CERAMIC	220PF	10%	50V	C740	1-162-282-31	CERAMIC	100PF	10%	50V
						C741	1-162-294-31	CERAMIC	1000PF	10%	50V
						C742	1-162-294-31	CERAMIC	1000PF	10%	50V
						< CERAMIC FILTER >					
						CF601	1-567-775-11	VIBRATOR, CERAMIC (4.19MHz)			
						CF701	1-579-233-11	VIBRATOR, CERAMIC (5MHz)			
						< CONNECTOR >					
						CN601	1-764-005-21	CONNECTOR, FFC/FPC 21P			
						* CN602	1-568-856-11	SOCKET, CONNECTOR 13P			
						< COMPOSITION CIRCUIT BLOCK >					
						* CP601	1-233-216-11	COMPOSITION CIRCUIT BLOCK			
						CP701	1-239-505-11	COMPOSITION CIRCUIT BLOCK			

The components identified by mark
△ or dotted line with mark △ are
critical for safety.
Replace only with part number
specified.

Les composants identifiés par une
marque △ sont critiques pour la
sécurité.
Ne les remplacer que par une pièce
portant le numéro spécifié.

PANEL

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
< DIODE >				< TRANSISTOR >			
D601	8-719-987-63	DIODE 1N4148M		Q601	8-729-119-78	TRANSISTOR 2SC2785-HFE	
D602	8-719-987-63	DIODE 1N4148M		Q602	8-729-900-80	TRANSISTOR DTC114ES	
D603	8-719-987-63	DIODE 1N4148M		Q604	8-729-018-23	TRANSISTOR TPS626	
D604	8-719-987-63	DIODE 1N4148M		Q612	8-729-119-78	TRANSISTOR 2SC2785-HFE	
D619	8-719-301-43	DIODE SEL2410E-C-TP6 (▷)		Q613	8-729-119-78	TRANSISTOR 2SC2785-HFE	
D620	8-719-301-59	DIODE SEL2910A (DISC 4)		Q701	8-729-119-78	TRANSISTOR 2SC2785-HFE	
D621	8-719-301-59	DIODE SEL2910A (DISC 3)		Q703	8-729-900-80	TRANSISTOR DTC114ES	
D622	8-719-301-59	DIODE SEL2910A (DISC 2)		Q704	8-729-900-80	TRANSISTOR DTC114ES	
D623	8-719-301-59	DIODE SEL2910A (DISC 1)		Q705	8-729-900-80	TRANSISTOR DTC114ES	
D624	8-719-301-59	DIODE SEL2910A (DISC 5)		Q706	8-729-900-80	TRANSISTOR DTC114ES	
D625	8-719-301-43	DIODE SEL2410E-C-TP6 (DISC 4)		Q707	8-729-900-80	TRANSISTOR DTC114ES	
D626	8-719-301-43	DIODE SEL2410E-C-TP6 (DISC 3)		Q708	8-729-900-80	TRANSISTOR DTC114ES	
D627	8-719-301-43	DIODE SEL2410E-C-TP6 (DISC 2)		Q709	8-729-900-80	TRANSISTOR DTC114ES	
D628	8-719-301-43	DIODE SEL2410E-C-TP6 (DISC 1)		Q710	8-729-900-80	TRANSISTOR DTC114ES	
D629	8-719-301-43	DIODE SEL2410E-C-TP6 (DISC 5)		< RESISTOR >			
D630	8-719-029-95	DIODE TLN117		R601	1-249-423-11	CARBON 3.3K 5% 1/4W	
D701	8-719-987-63	DIODE 1N4148M		R602	1-249-423-11	CARBON 3.3K 5% 1/4W	
D702	8-719-987-63	DIODE 1N4148M		R603	1-249-423-11	CARBON 3.3K 5% 1/4W	
D703	8-719-987-63	DIODE 1N4148M		R604	1-249-423-11	CARBON 3.3K 5% 1/4W	
D704	8-719-812-44	LED TL0124 (REC TIMER)		R605	1-249-429-11	CARBON 10K 5% 1/4W	
D705	8-719-032-87	DIODE SEL5420E-TP (DAILY)		R606	1-249-429-11	CARBON 10K 5% 1/4W	
D706	8-719-032-87	DIODE SEL5420E-TP (ONCE)		R607	1-249-429-11	CARBON 10K 5% 1/4W	
D707	8-719-026-64	DIODE SML1260S (PRESET)		R608	1-249-429-11	CARBON 10K 5% 1/4W	
D708	8-719-026-64	DIODE SML1260S (AUTO)		R609	1-249-429-11	CARBON 10K 5% 1/4W	
D709	8-719-026-64	DIODE SML1260S (TUNING)		R610	1-249-429-11	CARBON 10K 5% 1/4W	
D710	8-719-032-87	DIODE SEL5420E-TP (TUNER/BAND)		R611	1-249-429-11	CARBON 10K 5% 1/4W	
D711	8-719-987-63	DIODE 1N4148M		R612	1-249-429-11	CARBON 10K 5% 1/4W	
D712	8-719-987-63	DIODE 1N4148M		R613	1-249-429-11	CARBON 10K 5% 1/4W	
< FLUORESCENT INDICATOR >				R614	1-249-429-11	CARBON 10K 5% 1/4W	
FL601	1-519-738-11	INDICATOR TUBE, FLUORESCENT		R615	1-249-423-11	CARBON 3.3K 5% 1/4W	
FLT701	1-517-215-11	INDICATOR TUBE, FLUORESCENT		R617	1-249-423-11	CARBON 3.3K 5% 1/4W	
< IC >				R618	1-249-423-11	CARBON 3.3K 5% 1/4W	
IC601	8-759-295-57	IC uPD75518GF-243-3B9		R619	1-249-423-11	CARBON 3.3K 5% 1/4W	
IC602	8-759-254-76	IC M66004M4FP-T2		R620	1-249-409-11	CARBON 220 5% 1/4W	
IC603	8-759-165-81	IC PST600D-T		R621	1-249-409-11	CARBON 220 5% 1/4W	
IC701	8-759-292-05	IC uPD78043GF-097-3B9		R622	1-249-409-11	CARBON 220 5% 1/4W	
IC702	8-749-923-34	LE D GPIU59XB		R623	1-249-409-11	CARBON 220 5% 1/4W	
IC703	8-759-165-81	IC PST600D-T		R624	1-249-409-11	CARBON 220 5% 1/4W	
< COIL >				R625	1-249-410-11	CARBON 270 5% 1/4W	
L601	1-410-521-11	INDUCTOR 100uH		R626	1-249-410-11	CARBON 270 5% 1/4W	
L602	1-410-521-11	INDUCTOR 100uH		R627	1-249-410-11	CARBON 270 5% 1/4W	
L603	1-410-521-11	INDUCTOR 100uH		R628	1-249-410-11	CARBON 270 5% 1/4W	
L701	1-410-521-11	INDUCTOR 100uH		R629	1-249-410-11	CARBON 270 5% 1/4W	
L702	1-410-521-11	INDUCTOR 100uH		R630	1-249-411-11	CARBON 330 5% 1/4W	
				R631	1-249-393-11	CARBON 10 5% 1/4W	
				R632	1-249-425-11	CARBON 4.7K 5% 1/4W	
				R633	1-249-429-11	CARBON 10K 5% 1/4W	
				R635	1-249-417-11	CARBON 1K 5% 1/4W	

Ref. No.	Part No.	Description	Remark			Ref. No.	Part No.	Description	Remark		
R636	1-249-417-11	CARBON	1K	5%	1/4W	R720	1-249-429-11	CARBON	10K	5%	1/4W
R637	1-249-432-11	CARBON	18K	5%	1/4W	R721	1-249-429-11	CARBON	10K	5%	1/4W
R638	1-247-891-00	CARBON	330K	5%	1/4W	R722	1-249-393-11	CARBON	10	5%	1/4W
R651	1-249-413-11	CARBON	470	5%	1/4W	R723	1-249-429-11	CARBON	10K	5%	1/4W
R652	1-249-413-11	CARBON	470	5%	1/4W	R724	1-249-433-11	CARBON	22K	5%	1/4W
R653	1-249-413-11	CARBON	470	5%	1/4W	R725	1-249-437-11	CARBON	47K	5%	1/4W
R654	1-249-413-11	CARBON	470	5%	1/4W	R726	1-249-437-11	CARBON	47K	5%	1/4W
R655	1-249-415-11	CARBON	680	5%	1/4W	R727	1-249-437-11	CARBON	47K	5%	1/4W
R656	1-249-415-11	CARBON	680	5%	1/4W	R728	1-249-437-11	CARBON	47K	5%	1/4W
R657	1-249-415-11	CARBON	680	5%	1/4W	R729	1-249-429-11	CARBON	10K	5%	1/4W
R658	1-249-415-11	CARBON	680	5%	1/4W	R730	1-249-429-11	CARBON	10K	5%	1/4W
R659	1-249-417-11	CARBON	1K	5%	1/4W	R731	1-249-429-11	CARBON	10K	5%	1/4W
R660	1-249-417-11	CARBON	1K	5%	1/4W	R733	1-249-409-11	CARBON	220	5%	1/4W
R661	1-249-417-11	CARBON	1K	5%	1/4W	R734	1-249-408-11	CARBON	180	5%	1/4W
R662	1-249-417-11	CARBON	1K	5%	1/4W	R735	1-249-408-11	CARBON	180	5%	1/4W
R663	1-249-419-11	CARBON	1.5K	5%	1/4W	R736	1-249-413-11	CARBON	470	5%	1/4W
R664	1-249-419-11	CARBON	1.5K	5%	1/4W	R737	1-249-408-11	CARBON	180	5%	1/4W
R665	1-249-419-11	CARBON	1.5K	5%	1/4W	R738	1-249-429-11	CARBON	10K	5%	1/4W
R666	1-249-419-11	CARBON	1.5K	5%	1/4W	R739	1-249-429-11	CARBON	10K	5%	1/4W
R667	1-249-421-11	CARBON	2.2K	5%	1/4W	R740	1-247-891-00	CARBON	330K	5%	1/4W
R668	1-249-421-11	CARBON	2.2K	5%	1/4W	R741	1-249-429-11	CARBON	10K	5%	1/4W
R669	1-249-430-11	CARBON	12K	5%	1/4W	R742	1-249-417-11	CARBON	1K	5%	1/4W
R670	1-249-421-11	CARBON	2.2K	5%	1/4W	R743	1-249-417-11	CARBON	1K	5%	1/4W
R671	1-249-425-11	CARBON	4.7K	5%	1/4W	R780	1-249-421-11	CARBON	2.2K	5%	1/4W
R672	1-249-425-11	CARBON	4.7K	5%	1/4W	< SWITCH >					
R673	1-249-427-11	CARBON	6.8K	5%	1/4W F	S601	1-572-184-11	SWITCH, KEYBOARD	▶▶▶▶▶▶▶▶▶▶		
R674	1-249-425-11	CARBON	4.7K	5%	1/4W	S602	1-572-184-11	SWITCH, KEYBOARD	◀◀◀◀◀◀◀◀◀◀		
R675	1-249-430-11	CARBON	12K	5%	1/4W	S603	1-572-184-11	SWITCH, KEYBOARD	□		
R676	1-249-430-11	CARBON	12K	5%	1/4W	S604	1-572-184-11	SWITCH, KEYBOARD	▷		
R678	1-249-430-11	CARBON	12K	5%	1/4W	S605	1-572-184-11	SWITCH, KEYBOARD	(DISC 1)		
R680	1-249-421-11	CARBON	2.2K	5%	1/4W	S606	1-572-184-11	SWITCH, KEYBOARD	△		
R701	1-249-423-11	CARBON	3.3K	5%	1/4W	S607	1-572-184-11	SWITCH, KEYBOARD	(CHECK)		
R702	1-249-413-11	CARBON	470	5%	1/4W	S608	1-572-184-11	SWITCH, KEYBOARD	□□		
R703	1-249-415-11	CARBON	680	5%	1/4W	S609	1-572-184-11	SWITCH, KEYBOARD	(DISC 2)		
R704	1-249-417-11	CARBON	1K	5%	1/4W	S610	1-572-184-11	SWITCH, KEYBOARD	△		
R705	1-249-423-11	CARBON	3.3K	5%	1/4W	S611	1-572-184-11	SWITCH, KEYBOARD	(CLEAR)		
R706	1-249-413-11	CARBON	470	5%	1/4W	S612	1-572-184-11	SWITCH, KEYBOARD	(CONTINUE)		
R707	1-249-415-11	CARBON	680	5%	1/4W	S613	1-572-184-11	SWITCH, KEYBOARD	(DISC 3)		
R708	1-249-417-11	CARBON	1K	5%	1/4W	S614	1-572-184-11	SWITCH, KEYBOARD	△		
R709	1-249-419-11	CARBON	1.5K	5%	1/4W	S615	1-572-184-11	SWITCH, KEYBOARD	(EDIT)		
R710	1-249-421-11	CARBON	2.2K	5%	1/4W	S616	1-572-184-11	SWITCH, KEYBOARD	(SHUFFLE)		
R711	1-249-425-11	CARBON	4.7K	5%	1/4W	S617	1-572-184-11	SWITCH, KEYBOARD	(DISC 4)		
R712	1-249-417-11	CARBON	1K	5%	1/4W	S618	1-572-184-11	SWITCH, KEYBOARD	△		
R713	1-249-417-11	CARBON	1K	5%	1/4W	S619	1-572-184-11	SWITCH, KEYBOARD	(MEMO CHECK)		
R714	1-249-417-11	CARBON	1K	5%	1/4W	S620	1-572-184-11	SWITCH, KEYBOARD	(PROGRAM)		
R715	1-249-417-11	CARBON	1K	5%	1/4W	S621	1-572-184-11	SWITCH, KEYBOARD	(DISC 5)		
R716	1-249-417-11	CARBON	1K	5%	1/4W	S622	1-572-184-11	SWITCH, KEYBOARD	△		
R717	1-249-417-11	CARBON	1K	5%	1/4W	S624	1-572-184-11	SWITCH, KEYBOARD	(REPEAT)		
R718	1-249-417-11	CARBON	1K	5%	1/4W	S625	1-572-184-11	SWITCH, KEYBOARD	(CHARACTOR)		
R719	1-249-425-11	CARBON	4.7K	5%	1/4W						

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
S626	1-572-184-11	SWITCH, KEYBOARD (CHARACTOR)		C29	1-163-031-11	CERAMIC CHIP 0.01uF	50V
S628	1-572-184-11	SWITCH, KEYBOARD (CURSOR)		C31	1-124-257-00	ELECT 2.2uF 20%	50V
S629	1-572-184-11	SWITCH, KEYBOARD (MEMO INPUT)		C32	1-163-031-11	CERAMIC CHIP 0.01uF	50V
S630	1-572-184-11	SWITCH, KEYBOARD (ERASE)		C33	1-163-038-00	CERAMIC CHIP 0.1uF	25V
S631	1-572-184-11	SWITCH, KEYBOARD (TIME)		C34	1-163-038-00	CERAMIC CHIP 0.1uF	25V
S632	1-572-184-11	SWITCH, KEYBOARD (S, F, FILE)		C51	1-163-031-11	CERAMIC CHIP 0.01uF	50V
S701	1-572-184-11	SWITCH, KEYBOARD (TUNER/BAND)		C52	1-126-162-11	ELECT 3.3uF 20%	50V
S702	1-572-184-11	SWITCH, KEYBOARD (MODE)		C53	1-163-031-11	CERAMIC CHIP 0.01uF	50V
S703	1-572-184-11	SWITCH, KEYBOARD (MEMORY/NEXT)		C54	1-163-031-11	CERAMIC CHIP 0.01uF	50V
S704	1-572-184-11	SWITCH, KEYBOARD (STEREO/MONO)		C55	1-163-105-00	CERAMIC CHIP 33PF 5%	50V
S705	1-572-184-11	SWITCH, KEYBOARD (CLOCK SET)		C57	1-164-346-11	CERAMIC CHIP 1uF	16V
S706	1-572-184-11	SWITCH, KEYBOARD (TIMER SET)		C58	1-164-346-11	CERAMIC CHIP 1uF	16V
S707	1-572-184-11	SWITCH, KEYBOARD (ONCE)		C59	1-164-346-11	CERAMIC CHIP 1uF	16V
S708	1-572-184-11	SWITCH, KEYBOARD (DAILY)		C60	1-163-038-00	CERAMIC CHIP 0.1uF	25V
S709	1-572-184-11	SWITCH, KEYBOARD (REC TIMER)		C61	1-163-022-00	CERAMIC CHIP 0.012uF 10%	50V
S710	1-572-184-11	SWITCH, KEYBOARD (SLEEP)		C61	1-163-023-00	CERAMIC CHIP 0.015uF	(E, JE, AR, MX) 50V
S711	1-572-184-11	SWITCH, KEYBOARD (DISPLAY)		C62	1-163-022-00	CERAMIC CHIP 0.012uF 10%	(US, CND) 50V
S901	1-467-914-11	ENCODER, ROTARY (MULTI CONTROLLER)		C62	1-163-023-00	CERAMIC CHIP 0.015uF	(E, JE, AR, MX) 50V
< VIBRATOR >							
XT701	1-567-098-41	VIBRATOR, CRYSTAL (32.768kHz)		C63	1-126-301-11	ELECT 1uF 20%	50V
*****				C64	1-126-301-11	ELECT 1uF 20%	50V
*	A-4303-461-A	TCB BOARD, COMPLETE (E, JE, AR, MX)		C65	1-126-301-11	ELECT 1uF 20%	50V
*****				C66	1-126-301-11	ELECT 1uF 20%	50V
*	A-4303-462-A	TCB BOARD, COMPLETE (US, CND)		C70	1-163-031-11	CERAMIC CHIP 0.01uF	50V
*****				C71	1-163-031-11	CERAMIC CHIP 0.01uF	50V
< CAPACITOR >				C72	1-126-934-11	ELECT 220uF 20%	16V
C1	1-126-934-11	ELECT 220uF 20%	16V	C73	1-124-257-00	ELECT 2.2uF 20%	50V
C2	1-163-031-11	CERAMIC CHIP 0.01uF	50V	C74	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C3	1-163-009-11	CERAMIC CHIP 1000PF 10%	50V	C75	1-126-157-11	ELECT 10uF 20%	16V
C5	1-163-033-00	CERAMIC CHIP 0.022uF	50V	C76	1-126-933-11	ELECT 100uF 20%	16V
C6	1-163-091-00	CERAMIC CHIP 8PF 0.25PF	50V	C77	1-163-117-00	CERAMIC CHIP 100PF 5%	50V
C7	1-163-227-11	CERAMIC CHIP 10PF 0.5PF	50V	C78	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C12	1-164-343-11	CERAMIC CHIP 0.056uF 10%	25V	C79	1-126-157-11	ELECT 10uF 20%	16V
C13	1-163-033-11	CERAMIC CHIP 0.022uF	(E, JE, AR, MX) 50V	C80	1-126-925-11	ELECT 470uF 20%	10V
C14	1-163-088-00	CERAMIC CHIP 5PF 0.25PF	(E, JE, AR, MX) 50V	C81	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C21	1-163-099-00	CERAMIC CHIP 18PF 5%	50V	C82	1-163-031-11	CERAMIC CHIP 0.01uF	50V
C22	1-163-099-00	CERAMIC CHIP 18PF 5%	50V	C86	1-163-016-00	CERAMIC CHIP 3900PF 10%	50V
C23	1-163-031-11	CERAMIC CHIP 0.01uF	50V	C87	1-163-016-00	CERAMIC CHIP 3900PF 10%	50V
C24	1-163-031-11	CERAMIC CHIP 0.01uF	50V	< FILTER >			
C25	1-163-031-11	CERAMIC CHIP 0.01uF	50V	CF1	1-567-389-11	FILTER, CERAMIC	
C26	1-164-346-11	CERAMIC CHIP 1uF	16V	CF51	1-567-389-11	FILTER, CERAMIC	
C27	1-124-257-00	ELECT 2.2uF 20%	50V	< TERMINAL >			
C28	1-163-031-11	CERAMIC CHIP 0.01uF	50V	* CN3	1-537-613-11	TERMINAL (8P)	

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
		< VARIABLE CAPACITOR >					
CV1	1-141-227-00	CAP, TRIMMER (E, JE, AR, MX)		Q52	8-729-602-21	TRANSISTOR 2SC4154-F	
CV2	1-141-227-00	CAP, TRIMMER (E, JE, AR, MX)		Q53	8-729-810-28	TRANSISTOR 2SC4398	
		< DIODE >				< RESISTOR >	
D1	8-719-976-30	DIODE KV1560N (E, JE, AR, MX)		R1	1-216-037-00	METAL CHIP 330 5%	1/10W
D21	8-719-422-46	DIODE MA8056		R2	1-216-037-00	METAL CHIP 330 5%	1/10W
D51	8-719-016-74	DIODE 1SS352		R3	1-216-109-00	METAL CHIP 330K 5%	1/10W
		< FRONT END >		R4	1-216-037-00	METAL CHIP 330 5%	1/10W
FE1	1-465-673-11	FRONT END (2 BAND)		R7	1-216-017-00	METAL CHIP 47 5%	1/10W
FE2	1-239-260-11	ESCAPSULATED COMPONENT (US, CND)		R8	1-216-073-00	METAL CHIP 10K 5%	1/10W (E, JE, AR, MX)
FE2	1-239-262-11	ESCAPSULATED COMPONENT (E, JE, AR, MX)		R9	1-216-089-11	METAL CHIP 47K 5%	1/10W
		< IC >		R10	1-216-097-11	METAL CHIP 100K 5%	1/10W
IC21	8-759-821-43	IC LC7218M		R16	1-216-073-00	METAL CHIP 10K 5%	1/10W (E, JE, AR, MX)
IC51	8-759-823-68	IC LA1851NM		R17	1-216-121-00	METAL CHIP 1M 5%	1/10W (E, JE, AR, MX)
		< TRANSFORMER >		R18	1-216-073-00	METAL CHIP 10K 5%	1/10W (E, JE, AR, MX)
IFT51	1-406-821-11	COIL (DISCRIMINATOR)		R21	1-216-049-00	METAL CHIP 1K 5%	1/10W
IFT52	1-404-713-11	TRANSFORMER, IF		R22	1-216-049-00	METAL CHIP 1K 5%	1/10W
		< JUMPER RESISTOR >		R23	1-216-049-00	METAL CHIP 1K 5%	1/10W
JW1	1-216-295-00	METAL CHIP 0 5% 1/10W		R24	1-216-025-00	METAL CHIP 100 5%	1/10W
JW2	1-216-295-00	METAL CHIP 0 5% 1/10W		R25	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
JW3	1-216-295-00	METAL CHIP 0 5% 1/10W		R26	1-216-049-00	METAL CHIP 1K 5%	1/10W
		(E, JE, AR, MX)		R27	1-216-073-00	METAL CHIP 10K 5%	1/10W (E, JE, AR, MX)
JW4	1-216-295-00	METAL CHIP 0 5% 1/10W (US, CND)		R28	1-216-073-00	METAL CHIP 10K 5%	1/10W
JW5	1-216-295-00	METAL CHIP 0 5% 1/10W (US, CND)		R29	1-216-025-00	METAL CHIP 100 5%	1/10W
JW6	1-216-295-00	METAL CHIP 0 5% 1/10W		R30	1-216-061-00	METAL CHIP 3.3K 5%	1/10W
		< COIL >		R31	1-216-043-00	METAL CHIP 560 5%	1/10W
L51	1-408-798-00	CHIP INDUCTOR 1MMH		R32	1-216-049-00	METAL CHIP 1K 5%	1/10W
		< FILTER >		R33	1-216-035-00	METAL CHIP 270 5%	1/10W
LPF51	1-239-597-11	FILTER, LOW PASS		R34	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
LPF52	1-239-597-11	FILTER, LOW PASS		R35	1-216-057-00	METAL CHIP 2.2K 5%	1/10W
		< TRANSISTOR >		R36	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
Q1	8-729-804-72	TRANSISTOR 2SC2814-F4		R37	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
Q3	8-729-810-16	TRANSISTOR 2SA1678		R38	1-216-025-00	METAL CHIP 100 5%	1/10W
Q4	8-729-602-36	TRANSISTOR 2SA1602-F (E, JE, AR, MX)		R51	1-216-049-00	METAL CHIP 1K 5%	1/10W
Q5	8-729-602-36	TRANSISTOR 2SA1602-F (E, JE, AR, MX)		R52	1-216-081-00	METAL CHIP 22K 5%	1/10W
Q6	8-729-810-28	TRANSISTOR 2SC4398 (E, JE, AR, MX)		R53	1-216-085-00	METAL CHIP 33K 5%	1/10W
Q7	8-729-810-28	TRANSISTOR 2SC4398 (E, JE, AR, MX)		R54	1-216-071-00	METAL CHIP 8.2K 5%	1/10W
Q21	8-729-602-21	TRANSISTOR 2SC4154-F		R55	1-216-075-00	METAL CHIP 12K 5%	1/10W
Q22	8-729-232-69	TRANSISTOR 2SK208GR3		R57	1-216-073-00	METAL CHIP 10K 5%	1/10W
Q23	8-729-232-59	TRANSISTOR 2SC4666B		R58	1-216-066-00	METAL CHIP 5.1K 5%	1/10W
Q51	8-729-602-21	TRANSISTOR 2SC4154-F		R59	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
				R60	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
				R61	1-216-115-00	METAL CHIP 560K 5%	1/10W
				R62	1-216-115-00	METAL CHIP 560K 5%	1/10W
				R63	1-216-049-00	METAL CHIP 1K 5%	1/10W
				R64	1-216-049-00	METAL CHIP 1K 5%	1/10W

TCB

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R65	1-216-073-00	METAL CHIP 10K 5%	1/10W	*****			
R66	1-216-073-00	METAL CHIP 10K 5%	1/10W	*****			
R67	1-216-057-00	METAL CHIP 2.2K 5%	1/10W	*****			
R68	1-216-057-00	METAL CHIP 2.2K 5%	1/10W	*****			
R69	1-216-025-00	METAL CHIP 100 5%	1/10W	*****			
R70	1-216-025-00	METAL CHIP 100 5%	1/10W	*****			
R71	1-216-089-11	METAL CHIP 47K 5%	1/10W	*****			
R72	1-216-073-00	METAL CHIP 10K 5%	1/10W	*****			
R73	1-216-073-00	METAL CHIP 10K 5%	1/10W	*****			
R74	1-216-013-00	METAL CHIP 33 5%	1/10W	*****			
< VARIABLE RESISTOR >				*****			
RV51	1-238-601-11	RES, ADJ, CARBON 22K		*****			
RV52	1-238-601-11	RES, ADJ, CARBON 22K		*****			
RV53	1-238-598-11	RES, ADJ, CARBON 2.2K		*****			
< COIL >				*****			
T1	1-402-424-11	COIL (ANT, SW3) (E, JE, AR, MX)		*****			
T2	1-406-346-11	COIL (OSC, SW3) (E, JE, AR, MX)		*****			
< CONNECTOR >				*****			
TP51	1-564-505-11	PLUG, CONNECTOR 2P		*****			
< VIBRATOR >				*****			
X21	1-579-585-11	VIBRATOR, CRYSTAL (7.2MHz)		*****			
X51	1-577-075-11	OSCILLATOR, CERAMIC (456kHz)		*****			
*****				*****			
MISCELLANEOUS				*****			
*****				*****			
6	1-769-271-11	WIRE (FLAT TYPE) (13 CORE)		*****			
7	1-751-690-11	WIRE (FLAT TYPE) (21 CORE)		*****			
60	1-452-676-11	MAGNET		*****			
△155	8-848-144-11	DEVICE, OPTICAL KSS-240A		*****			
156	1-575-001-11	WIRE, FLAT TYPE (12 CORE)		*****			
158	1-751-659-11	WIRE (FLAT TYPE) (22 CORE)		*****			
FL601	1-519-738-11	INDICATOR TUBE, FLUORESCENT		*****			
FLT701	1-517-215-11	INDICATOR TUBE, FLUORESCENT		*****			
M101	A-4660-586-A	MOTOR ASSY (LOADING MOTOR)		*****			
M102	A-4660-586-A	MOTOR ASSY (UP/DOWN MOTOR)		*****			
M103	A-4660-232-A	MOTOR (CDM) ASSY (CLAMP MOTOR)		*****			
M104	X-4917-523-4	MOTOR ASSY (SPINDLE MOTOR)		*****			
M105	X-4917-504-1	MOTOR ASSY (SLED MOTOR)		*****			
S902	1-466-819-11	ENCODER, ROTARY		*****			
*****				*****			

The components identified by mark △ or dotted line with mark △ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

MEMO

REVISION HISTORY

Clicking the version allows you to jump to the revised page.

Also, clicking the version at the upper right on the revised page allows you to jump to the next revised page.

[illegible]